



Face Seal



Poly and Wire Brush



Clutch



Belt



L/C Blade



Spiral Point




Blade



Tagged Blade



Beam



Blade



Blade



PTO Shaft



Stub Axle Shaft

For more info about our  
spare parts, please contact:

Tel : 085-655855 (General)

085-655675 (Parts)

Email : [partshq@dailieng.com.my](mailto:partshq@dailieng.com.my)